



A	B	G	L	K	F	D	P
1x	1x	3x	2x	6x	1x	1x	5x



MANUTENZIONE MECCANISMI: non necessita di manutenzione. Controllare periodicamente il serraggio delle viti e assicurarsi che tutte le viti e tutti i bulloni siano serrati.

In generale, si consiglia di eseguire la manutenzione ordinaria ogni 6 mesi circa.

PULIZIA: superfici vernicate e plastiche: utilizzare un panno morbido umido con sapone neutro; ripassare solo con un panno umido.

USO: evitare l'uso improprio; es. sedersi su uno dei braccioli, salire sul sedile etc.
Durante lo spostamento evitare di stare seduti e fare attenzione a eventuali dislivelli, canaline, ecc.

AMBIENTE: Ricordiamo l'importanza di un corretto disassemblaggio e smaltimento a fine vita del prodotto secondo i regolamenti territoriali.

MECHANISM MAINTENANCE: do not require maintenance. Periodically check the screws and make sure every screws and bolts are tightened.

In general, it is suggested to execute maintenance routine about every 6 months.
There are no other specific requirements for the above product.

CLEANING: painted and plastic surfaces: use a soft damped cloth and mild soap;
just wipe again with a damp cloth only.

USE: avoid improper use; ex. sit on one of the armrests, jump on the seat etc.

ENVIRONMENT: We remind you the importance of a correct disassembly and disposal at the end of life of the product according to the territorial regulations.